

Network device template MV110-16X

Application on controllers		PR200-X.X.1(2)	
Variable Name	Data type	Register address	Comment
Time-out, s (t.out)	INT	48	Maximum time allowed without command
Input status bitmask	INT	51	
Counter status of the input 1	INT	64	Number of activations of input №1
Counter status of the input 2	INT	65	Number of activations of input №2
Counter status of the input 3	INT	66	Number of activations of input №3
Counter status of the input 4	INT	67	Number of activations of input №4
Counter status of the input 5	INT	68	Number of activations of input №5
Counter status of the input 6	INT	69	Number of activations of input №6
Counter status of the input 7	INT	70	Number of activations of input №7
Counter status of the input 8	INT	71	Number of activations of input №8
Counter status of the input 9	INT	72	Number of activations of input №9
Counter status of the input 10	INT	73	Number of activations of input №10
Counter status of the input 11	INT	74	Number of activations of input №11
Counter status of the input 12	INT	75	Number of activations of input №12
Counter status of the input 13	INT	76	Number of activations of input №13
Counter status of the input 14	INT	77	Number of activations of input №14
Counter status of the input 15	INT	78	Number of activations of input №15
Counter status of the input 16	INT	79	Number of activations of input №16

The templates do not indicate all registers available for network exchange; to clarify the necessary information, please refer to the operating manual for the corresponding device.

Scope of application:

1. Can be used to quickly configure a device when working with a network device in **Master mode**

Version	1.0
Last modification	22.04.2024.