


Logical function 4NOT



Input	Data type	Description
I1	BOOL	Eingang 1
I2	BOOL	Eingang 2
I3	BOOL	Eingang 3
I4	BOOL	Eingang 4
Output	Data type	Description
Q1	BOOL	Inverted input I1
Q2	BOOL	Inverted input I2
Q3	BOOL	Inverted input I3
Q4	BOOL	Inverted input I4

Function

The 4NOT function inverts the input status.

The output is 1 if the input is 0.

The output is 0 if the input is 1.

Truth table

I1	Q1	I2	Q2	I3	Q3	I4	Q4
1	0	1	0	1	0	1	0
0	1	0	1	0	1	0	1

Devices	PR110, PR114, PR200
Version	Last modification
1.0	27.02.2015